

Mi THE MASTER SERIES

Model No CX1000

Automatic Universal Lithium Ion Video/Camcorder/Digital Camera Battery Charger

This universal battery charger comes attractively packaged in a clam shell than can be hung or free standing. The unit has a built in base plate & includes additional adaptor plates that between them will fit the majority of most brand lithium ion camcorder batteries. Charging time - standard batteries will take around an hour to charge & high capacity batteries from 2-6 hours dependant on the battery capacity.

Input: 12VDC via car cigarette lighter plug or SAA approved 240VAC power supply included.

Output: 3.6V to 7.4V (Auto Detect) @ 800mA

CE Approved.

The standard package Includes the CX1000 charger, ac/dc adapter, cigarette lighter plug cord, video battery adaptor plates, user manual.



Available from:-

Mi Master Instruments

Sydney 33-39 Sloane St Marrickville NSW 2204

Phone (02) 95191200 Fax (02) 95194604 Email sales@master-instruments.com.au

Melbourne Unit 13 107 Heatherdale Rd Ringwood VIC 3134

Phone (03) 98726422 Fax (03) 98726466 Email vic@master-instruments.com.au

CX1000 UNIVERSAL LI-ION BATTERY CHARGER COMPATIBILITY CHART

Brand	Battery	Charge By	Brand	Battery	Charge By
Canon®	BP-911/914/915/941	Base unit	Kyocera®	BP-800S/1000S	Universal Plate
	BP-924/927/930/945	Base unit	Minolta®	NP-200	Universal Plate
	BP-511/512/522/535	Base unit	Nikon®	EN-EL1	Universal Plate
	BP-608/617	Adapter Plate A		EN-EL2	Universal Plate
	NB-1L	Universal Plate		EN-EL3	Universal Plate
	NB-1LH	Universal Plate	Olympus®	DB-L10	Universal Plate
	NB-2L	Universal Plate		LI-10B	Universal Plate
	BP-2L12,NB2F12	Universal Plate	Pentax®	D-LI2	Universal Plate
			D-L12/L17/L18	Universal Plate	
Fuji®	NP-30/40/60/80	Universal Plate	Polaroid®	PR-110DG	Universal Plate
	NP-80	Adapter Plate A	RCA®	BB-065L	Base unit
	NP-100/120	Universal Plate		BB-075/BB-075L	Adapter Plate A
	DRLB4	Universal Plate	Ricoh®	DB-30/40/43	Universal Plate
Hitachi®	VM-BPL-13/27/30/60	Base unit	Samsung®	SB-L160/L320/L480	Base unit
	VM-E330/535	Base unit	Sanyo®	VM-LC100	Base unit
	VM-NP500	Base unit		UR-211/421	Universal Plate
	VM-N520	Base unit		DB-L10	Universal Plate
JVC®	BN-V812/814	Base unit	Sharp®	BT-L1/L2	Adapter Plate A
	BN-V408/416/428	Base unit		BT-L11/BT-L12	Adapter Plate A
	BN-V607/615/628	Adapter Plate B		BT-L221/L441/L241/L41	Adapter Plate B
	BN-V712/714	Adapter Plate A		VR-BL72	Adapter Plate C
	BN-V507/514	Adapter Plate C		VR-BL91	Adapter Plate B
	J-I723	Adapter Plate B		BT-L31	Adapter Plate C
	BN-V907	Adapter Plate B		VR-BL71/75/81	Adapter Plate A
	BN-V214/V207	Adapter Plate C		BT-L226	Universal Plate
	BN-V101	Universal Plate		AD-S30BT	Universal Plate
				AD-S31BT	Universal Plate
Kodak®	KLIC-5000/3000	Universal Plate	AD-T50BT	Universal Plate	
Konica®	DR-LB1	Universal Plate	AD-T51BT	Universal Plate	
	DR-LB4	Universal Plate			
Panasonic®	VW-VBD1/E	Base unit	Sony®	NP-F300/330	Base unit
	VW-VBD2	Base unit		NP-F500/520	Base unit
	CGR-D120/110	Adapter Plate B		NP-F530/550	Base unit
	CGR-D210/220/320	Adapter Plate B		NP-F720/F730	Base unit
	VW-VBD21/23/24	Adapter Plate B		NP-F750	Base unit
	CGR-V610/620E	Adapter Plate C		NP-F930	Base unit
	CGR-D53A/V14/26	Adapter Plate B		NP-F950/F960	Base unit
	CGP-110E/120E	Adapter Plate B		NP-F730H	Base unit
	CGP-145/165/285	Adapter Plate B		NP-F100/F200	Base unit
	CGR-D16A/28A	Adapter Plate B		NP-FM50/70/90	Base unit
	CGR-D080A	Adapter Plate B		NP-QM51/71/91	Base unit
	CGR-B202	Adapter Plate B		NP-FF50/70	Base unit
	CGP-D14/16/21/28	Adapter Plate B		NP-FC10	Base unit
	CGR-S620E	Adapter Plate B		NP-F10/F20/F30	Adapter Plate B
	CGR-101	Universal Plate	NP-FS11/21/31	Adapter Plate B	
	DMW-BCA7	Universal Plate	Toshiba®	PDR-BT2	Adapter Plate A
	VW-VBP10	Universal Plate		PDR-BT3/BT9/BT1	Universal Plate
	CGA-DU07/14/21	Universal Plate	Thomson®	BAT600	Base unit

All brands are the property of their respective owners